



Alarms and Notifications

PERDIXPro provides the ability to set alarms for various device activity relating to trail cameras, traps tags and tracking tags. Alarms can also be set for device & system features, as well as animal recognition (AI).

These alarms can then be enabled to be sent as notifications, either via SMS (SMS credits required to be purchased via Add Ons), or by email which is free of charge.

Device Activity Alarms and Notifications

Alarms for device activity (i.e. images received, trap activations) are generated automatically at the top right hand corner of the PERDIXPro platform and App.




Users can enable notifications for these alarms within their own account for their individual Sites. These alarms can be enabled in two ways:

1. Open the PERDIXPro App, navigate to **Sites** > your chosen **Site** > click  > choose SMS or Email.
2. Log in to the PERDIXPro platform, navigate to **Sites** > All **Sites** > your chosen **Site** > click  > choose SMS or Email.


Device & System Alarms and Notifications

Alarms for device and systems features can be set and enabled, then be switched on by individual users to enable their own notifications.

To set these alarms, navigate to **Settings** > **Alarm Settings**. Here you will see the list of device and system alarms available. For the alarm you require, select the Enabled User Role(s) who can receive the alarm(s), and then set the alarm threshold within More Settings. Under Actions, you can create your own notification messages.



To enable these alarms, navigate to Alarms, and within your chosen alarm tab, toggle on and enable alarms. Alarms is where all your device & system alarms (and animal recognition AI alarms if enabled) are listed.



Once alarm settings are correct and the chosen alarms have been enabled, the individual users who are to be notified of an alarm will need to navigate within their account to **Alarms** > chosen alarm **tab** > click  > choose SMS or Email.

N.B. Ensure the individual user enabling their notifications for a particular alarm, has a User Role that has been listed against the alarm in Enabled User Roles.

Animal Recognition (AI) Alarms and Notifications

On request, the PERDIX team can apply Animal Recognition (AI) to your account. If enabled on your account, Alarms for animal recognition (AI) can be set and enabled, then be switched on by individual users to enable their own notifications.

To switch on animal recognition (AI) against your installed cameras, navigate to **Settings** > **AI Settings**. Under the AI Settings select the trail camera(s) you would like animal detection to be applied to, as well as the species to be detected.

To set a specific animal recognition (AI) alarm go to the AI Alarm Settings tab, select the Enabled User Role(s) to receive the alarm(s), and then set the accuracy threshold within More Settings for each species. Under Actions, you can create your own notification messages.

To enable these alarms, navigate to Alarms, and within the AI Alarms tab, toggle on and enable alarms.

Once alarms settings are correct and the chosen alarms have been enabled, the individual users who are to be notified of an alarm, will need to go to Alarms via their own account log in, navigate to the AI Alarm tab > click  > choose SMS or Email.

N.B. Ensure the individual user enabling their notifications for a particular alarm, has a User Role that has been listed against the alarm in Enabled User Roles.